



ASSEMBLY INSTRUCTIONS

CLIP SHELVING SWING DOORS

ANGLE POST

BEADED POST

1/4"-20 x 1" BOLT & NUT

CLIP # 103699

1/4"-20 x 5/8" BOLT & NUT

#10-24 X 3/8" BOLT, NUT, & LOCK WASHER

- NOTE: RIGHT HAND DOOR IS PUNCHED FOR HANDLE.
BOLT DOORS TO EACH HINGE USING 2- #10-24 X 3/8" BOLTS, NUTS, & LOCKWASHERS.
SQUARE DOORS IN FRAME OPENING BEFORE TIGHTENING BOLTS.
- BOLT DOOR & FRAME ASSEMBLY TO POST. USE 1/4"-20 X 5/8" BOLTS & NUTS FOR ANGLE POSTS (ONE BOLT & NUT PER EACH HINGE LOCATION).
FOR BEADED POSTS, ATTACH CLIPS TO POST USING 1/4"-20 X 1" BOLT & NUT (2 PER CLIP).
ATTACH DOOR AND FRAME ASSEMBLY TO CLIPS USING 1/4"-20 X 5/8" BOLTS & NUTS (2 PER CLIP).

LOCK ASSEMBLY DETAILS

- MOUNT HANDLE ON DOOR WITH 2 MACHINE SCREWS.
- INSERT LOCK BAR GUIDES INTO SLOTS ON TOP & BOTTOM OF DOOR. ENSURE GUIDES ARE LOCKED IN PLACE.
- MOUNT LOCK BARS ON LATCH AS SHOWN.
- ROTATE LATCH 90° CLOCKWISE (LOOKING INTO THE REAR FACE OF THE DOOR) AND HANDLE 90° COUNTER CLOCKWISE (LOOKING AT THE FRONT FACE OF THE DOOR) TO THE OPEN POSITION.
- INSERT LOCK BARS INTO GUIDES WHILE ALIGNING SQUARE HOLE IN LATCH WITH SQUARE THREADED SHOULDER ON HANDLE.
- APPLY JAM NUT.

